

# MicroLog V3A and V3/4.096

Battery replacement



*EMS Brno, December 2023*

# Notice:


Please note that there are two versions with different battery terminals:

- MicroLog with screw terminals
- MicroLog with screwless terminals - Wago (serial number starts with "B")

Both versions use LS 14250CNA battery, single cell, 3.6 V, 1/2AA, Lithium Thionyl Chloride, 900 mAh with axial wires.

The main difference between those models is in the wire adjustment of batteries – see pictures.

When asking manufacturer for new batteries, please specify the version (incl. prefix of serial number) and we will adjust battery terminals accordingly.



# Necessary tools and accessories:



Gloves

or



MicroLog  
opener



PC and  
IrDA/USB cable



Desiccant bag




Battery for screw  
terminals



Flat screwdriver  
2.5 mm



Battery for screwless  
terminals (Wago)




WAGO tool  
(for WAGO 2060  
terminals)

*For alternate parts of manual, due to terminal type, follow background colour*


# Datalogger opening

Screw out the datalogger lid by MicroLog opener or by hand (use non-slip gloves for better grip). If the datalogger is dirty, clean it before opening to prevent dirt from getting inside and on the lid threads.






# Battery replacement procedure



## SCREW TERMINALS





## SCREWLESS TERMINALS



*For alternate parts of manual, due to terminal type, follow background colour*



# SCREW TERMINALS - Battery removal

- Remember the battery polarity.
- Screw out the positive battery terminal and lift the battery wire.
- Screw out the negative terminal and remove the battery.
- Don't forget to recycle the battery.



# SCREW TERMINALS - Battery inserting

- Insert new battery back to terminals. Consider polarity! Screw it up firmly.
- It is good idea to write down the time stamp of battery replacement.
- Insert new desiccant bag.







# SCREWLESS TERMINALS - battery removal

- Release the positive battery terminal and remove the battery wire:
  - insert the end of the WAGO tool into the circular depression in WAGO 2060 terminal
  - lightly press **perpendicularly** on a push-button and remove the wire
- Release the negative battery terminal in the same way as positive terminal and remove the battery.
- Don't forget to recycle battery.



## **WARNING**

the plastic part is extremely fragile. Make sure to use appropriate tool!









# Battery removal – broken terminal

If you accidentally broke the push-button of WAGO terminal:



- remove the broken remains
- use the same WAGO tool for opening the clamping jaws
- slightly more force is required for opening (compared to a functional, not broken terminal)



Illustrative photos were taken on a different device type and may differ in certain details not relevant to this manual


# SCREWLESS TERMINALS - battery inserting

- Insert new battery. Consider polarity!
- Squeeze negative terminal and insert the battery wire.
- Squeeze positive terminal and insert the battery wire.
- It is good idea to write down the time stamp of battery replacement.
- Insert new desiccant bag.



# Datalogger closure

Make sure that both lid thread and seals are clean or clean them by brush before closing.



## Waterproofing

is ensured by a thread and a pair of sealing rings  
- one above the thread  
and the other on the  
bottom of the component  
containing the PCB and  
connectors.

**Always check if these  
parts are clean before  
closing**





# Datalogger closure

- Screw up the datalogger lid by hands (do not use opener!).
- Guide the thread carefully so that you do not screw "through the thread".




# Sensor set up

Run Mini32, connect the datalogger by IrDA/USB cable and go to Configuration. You will pass datalogger time synchronization:



# Battery counter

Reset the battery counter through Mini32: Configuration > More > Batt. reset.



MicroLog - SETTING UP - ADVANCED Mini32 v. 10.2.14.19

Less << Init RAM clear HCM Password Set time **Batt. reset**

PC Time: 08.11.2021 9:22:23  
DL Time: 19.09.2021 4:00:21


ON/off **ON**

Device type: V3A  
Device code 52  
Batt: 3,52 V


measuring Periods: 4 h Warm-up: 0 s  
storing 4 h

Battery remains: not available  
Memory capacity: 4681 days  
Overwrite ENABLE

#	Type	ON/off	Range	Gauge	Description
1.	Voltage	ON	2400 mV	Voltage	
2.	Voltage	ON	2400 mV	Voltage	
3.	Voltage	ON	2400 mV	Voltage	



Warning

 You are going to change the datalogger battery status (how many % of energy still remains). Take this action if there is a known discrepancy between the real and displayed battery status.

OK Abort



# Battery counter

- Choose the battery status of battery
- If inserted battery is used and only temporarily removed, choose this option and set remaining energy (%)

Battery counter reset

Battery status information has failed, probably due to battery replacement or temporary removal.  
If a used battery has been put back into the unit, please click on lower button and enter the estimated amount of remaining energy [%]. A recent data file could help.  
Note that older system don't need to support this option.

Battery status:

☒ new (replaced) battery

☐ used battery temporarily removed

Energy remaining:  %

OK

Battery counter reset

Battery status information has failed, probably due to battery replacement or temporary removal.  
If a used battery has been put back into the unit, please click on lower button and enter the estimated amount of remaining energy [%]. A recent data file could help.  
Note that older system don't need to support this option.

Battery status:

☐ new (replaced) battery


☒ used battery temporarily removed

Energy remaining:  %

OK

# Final check

Go back to Mini32 main screen and press "On-line" button. Check the actual values and all status information. You can also download the data to make sure that nothing happened with memory structure.



MicroLog - DATA HANDLING Mini32 v. 10.2.14.19

**Actual values** Regular reading ☐ el. values PrgmCalc Close

PC Time: 09.11.2021 13:45:38  
DL Time: 09.11.2021 13:45:36

**ON**

Device type: V3A  
Device code: 52  
Batt: 3,52 V

Periods :  
measuring 4 h / warm-up 0 s  
storing 4 h

Battery remains: not available  
Memory capacity: 4681 days  
Overwrite ENABLE

#	Type	No. Gauge	Electrical	Physical	Description
1.	Voltage	Voltage	26,1597	26,1597	
2.	Voltage	Voltage	13,642	13,642	
3.	Voltage	Voltage	106,288	106,288	

# Datalogger closure

- Screw up the datalogger lid by hands (do not use opener!).
- Guide the thread carefully so that you do not screw "through the thread".





**Good luck!**